

# CNC PREFLIGHT CHECKLIST

	CHECK work area
	CHECK spindle
	CHECK ballscrews
	CHECK e-stop
	turn ON compressor
	ATTACH compressor
	START CAMaster
	turn ON cnc
	INITIALIZE on CAMaster
	WARM up spindle
	turn ON air filtration
	turn ON dust collection

# CNC CLEANUP CHECKLIST

	ZERO spindle control
	REMOVE all bits from spindle
	PUT AWAY collet and bits or INSTANT DEATH 💀
	CLEAN work area
	PUT AWAY clamps+wrenches+hardware
	VACUUM cnc
	JOG machine to back right
	turn OFF compressor
	DETACH compressor
	turn OFF cnc
	CLOSE CAMaster
	turn OFF air filtration
	turn OFF dust collection